



EuroPHit_OP21_MosArt_Family Home_Ireland

OVE01 Verge detail for timber frame with timber cladding - Site Photo

BEFORE AFTER (STEP 1)









DESCRIPTION/CHALLENGES

In order to assure a continuous airtight line, it has been decided to keep the airtight layer along the outside of the existing block wall as the render, and lay on the existing roof rafters an airtight membrane that will meet the wall render at eaves and verge junctions.



The sole responsibility for the content of this publication lies with the authors. It does not necessarily reflect the opinion of the European Union. Neither the EACI nor the European Commission are responsible for any use that may be made of the information contained therein.



